Using Playaway Launchpad

Power On/Off
Audio Jack
USB Input
Volume

Go Back   Return Home

PLAYAWAY
launchpad

PLAYAWAY

Choose your explorer.

Start Playing

launchpad

PLAYAWAY

1,615

Battle Station | Critter Cruise | Fourth Grade Learning Games | Math Blaster Space Zapper | Math Planet – 4th Grade

Math Pop Grade 4 | Max & Ruby: Max's Mole Mash | Pizza Party | Scaredy Squirrel Stash N Crash | Solitaire

launchpad

Powering On/Off

To turn on, hold down ⏻ for three seconds.

To put in standby mode, press ⏻ one time briefly.

To turn off, hold down ⏻ for three seconds.

Navigating Launchpad

🔸 View app menu screen.

🔸 Customize your avatar by redeeming discovery points.

🔸 Visit informational console to view play time analytics.

Use the Android navigation bar to exit apps or return to home page. To make Android navigation bar appear, touch bottom of screen.

⮌ Exit current screen or "go back".

▭ Return to home page (reset or continue as current user).

Troubleshooting

Not turning on? Your Launchpad needs a power boost. Charge for five minutes using the power cord provided.

Need more help? Visit my.playaway.com for additional troubleshooting tips.